

## Installation on a PDA

maptrip runs on a PDA with Windows Mobile 5.0 or higher.

1. Make sure you have enough space on the SD card. To copy all data, you need a 4GB card, because the entire content of about 2GB in size.
2. Make sure that your PDA can handle a 4GB card. Not every PDA can handle SDHC cards, if it not necessary, you can delete parts of the maps of maptrip, what you dont need.
3. In the folder ... \CE\SDCARD they are three folders that you must completely on the SD card.
4. If you can not use 4GB card, copy first the three folders on your local hard disk and delete in the ... \CE\SDCARD\data\mapset\data\MapView\maps and ... \CE\SDCARD\data\mapset\data\routing\_geocoder cards are not required map data folder.
5. If the size is still above the max. available memory size, there is nor the possibility of delete unnecessary language deleted. These is be saved in the ... \CE\SDCARD\maptrip\res folder.
6. If all required data are erased, copy the three files from the local HDD to the SD card.
7. The folder structure should look like this.



8. The 2577 folder includes a startup file, which after loading and starting the PDA, start up the automatically installation of the software.
9. After first starting you will be informed that you must unlock the software. Please read the instructions to unlock. Please note the software hardware code with your PDA show on the display, you need this by new activation on this PDA. Be 100% sure, that you want to use the software on this PDA, when you have several PDA`s in use, the software and harware key will be paired by the installed PDA.

If you are in spite of these instructions or have any questions about installation, please contact the Navilock supportz under [support@navilock.de](mailto:support@navilock.de)

The manual of maptrip, gives further informations of the handling, please read this befor contact the Navilock Support.