

Declaration of conformity

Products with a CE symbol fulfill the RED directive (2014/53/EU) and RoHS directive (2011/65/EU+2015/863+2017/2102), which were released by the EU-commission.

The declaration of conformity can be downloaded here:
https://www.delock.de/produkte/G_90562/merkmale.html

Frequency band(s): 2402 - 2480 MHz

Maximum radio-frequency power transmitted: 1.28 mW EIRP

WEEE-notice

The WEEE (Waste Electrical and Electronic Equipment)-directive, which became effective as European law on February 13th 2003, resulted in an all out change in the disposal of disused electro devices. The primary purpose of this directive is the avoidance of electrical waste (WEEE) and at the same time the support of recycling and other forms of recycling in order to reduce waste. The WEEE-logo on the device and the package indicates that the device should not be disposed in the normal household garbage. You are responsible for taking the disused electrical and electronic devices to a respective collecting point. A separated collection and reasonable recycling of your electrical waste helps handling the natural resources more economical. Furthermore recycling of electrical waste is a contribution to keep the environment and thus also the health of men. Further information about disposal of electrical and electronic waste, recycling and the collection points are available in local organizations, waste management enterprises, in specialized trade and the producer of the device.

Battery guideline (2006/66/EC)

The built in battery is recyclable. Please dispose of it by using the battery container or dealer. Just dispose of the empty battery to guarantee the environmental protection.



EU Import: Tragant Handels- und Beteiligungs GmbH
Beeskowdamm 13/15, 14167 Berlin, Germany

 User manual

 Bedienungsanleitung

DELLOCK[®]
we move the world

Barcode Laser Scanner 1D for 2.4 GHz, Bluetooth and USB



Product-No: 90564
User manual no:90564-a
www.delock.com



Support Delock

If you have further questions, please contact our customer support
support@delock.de

You can find current product information on our homepage: www.delock.com

Final clause

Information and data contained in this manual are subject to change without notice in advance. Errors and misprints excepted.

Copyright

No part of this user's manual may be reproduced, or transmitted for any purpose, regardless in which way or by which means, electronically or mechanically, without explicit written approval of Delock.

Edition: 07/2022

Description

This barcode laser scanner by Delock can be connected directly to a PC or laptop. Alternatively, an adapter can be used to connect the scanner to a mobile phone or tablet. Up to 100 scans per second of all common 1D barcode types can be precisely captured, even at long distances.

Transmission via Bluetooth, USB or 2.4 GHz

The data transfer of the scanned barcodes is done either via Bluetooth directly with the Bluetooth capable output device or via the 2.4 GHz frequency band using the included USB dongle. Alternatively, the scanner can be connected to the computer with the included USB cable.

Specification

- Connector: 1 x USB 2.0 Type-B female
- Rechargeable battery: Li-Polymer battery 1800 mAh
- Decoding chip: ARM Cortex 32 Bit
- Resolution: 752 x 480
- Trigger: scan button
- Reading distance: ca. 185 mm to 300 mm
- Reading accuracy: 3 mil
- Scan type: laser class 1, 570 nm, <0,5 mW
- Scan rate: up to 100 scans per second
- Scan angle: 55°
- Input voltage: 5 V
- Current consumption:
operation: max. 100 mA
standby: max. 30 mA
- Operating temperature: 0 °C ~ 50 °C
- Storage temperature: -10 °C ~ 50 °C
- Relative humidity: 5 - 95 % (non condensing)
- Colour: black
- Weight: ca. 190 g
- Dimensions (LxWxH): ca. 170 x 90 x 70 mm
- Cable length without connectors: ca. 1.5 m
- Scancodes:
Code 128
Code 39
Code2of5 Interleaved
EAN-8 / EAN-13
ISBN - 13

System requirements

- Android 11.0 or above
- iPad Air (2020)
- iPad Pro (2018)
- Mac OS 12.3.1 or above
- Windows 8.1/8.1-64/10/10-64/11
- PC or laptop with a free USB Type-A port

Package content

- Barcode scanner
- USB 2.4 GHz dongle
- USB charging cable
- User manual

Kurzbeschreibung

Dieser Barcode Laser Scanner von Delock kann direkt mit einem PC oder Notebook verbunden werden. Alternativ lässt sich ein Adapter zwischenschalten, um den Scanner auch am Handy oder Tablet nutzen zu können. Es können bis zu 100 Scans in der Sekunde, aller gängigen 1D Barcodetypen, auch auf weite Entfernung präzise erfasst werden.

Übertragung via Bluetooth, USB oder 2,4 GHz

Die Datenübertragung der gescannten Barcodes erfolgt entweder über Bluetooth direkt mit dem bluetoothfähigem Ausgabegerät oder über das 2,4 GHz Frequenzband mit Hilfe des beiliegenden USB Dongles. Alternativ kann der Scanner mit dem beiliegendem USB Kabel am Rechner verbunden werden.

Spezifikation

- Anschluss: 1 x USB 2.0 Typ-B Buchse
- Akku: Li-Polymer 1800 mAh
- Dekodierchip: ARM Cortex 32 Bit
- Auflösung: 752 x 480
- Auslöser: Drucktaste
- Leseabstand: ca. 185 mm bis 300 mm
- Lesegenauigkeit: 3 mil
- Scan Art: Laser Klasse 1, 570 nm, <0,5 mW
- Scan Rate: bis zu 100 Scans pro Sekunde
- Scan Winkel: 55°
- Eingangsspannung: 5 V
- Stromaufnahme:
Betrieb: max. 100 mA
Standby: max. 30 mA
- Betriebstemperatur: 0 °C ~ 50 °C
- Lagerungstemperatur: -10 °C ~ 50 °C
- Relative Luftfeuchtigkeit: 5 - 95 % (nicht kondensierend)
- Farbe: schwarz
- Gewicht: ca. 190 g
- Maße (LxBxH): ca. 170 x 90 x 70 mm
- Kabellänge ohne Anschlüsse: ca. 1,5 m
- Scancodes:
Code 128
Code 39
Code2of5 Interleaved
EAN-8 / EAN-13
ISBN - 13

Systemvoraussetzungen

- Android 11.0 oder höher
- iPad Air (2020)
- iPad Pro (2018)
- Mac OS 12.3.1 oder höher
- Windows 8.1/8.1-64/10/10-64/11
- PC oder Notebook mit einem freien USB Typ-A Port

Packungsinhalt

- Barcode Scanner
- USB 2,4 GHz Dongle
- USB Ladekabel
- Bedienungsanleitung

Safety instructions

- Protect the product against moisture
- Protect the product against direct sunlight
- Do not look directly into the Laser diode of the scanner


Battery charging

You can charge the scanner's battery by using the included USB cable. For this, plug the USB Type-B connector into the scanner and the USB-A connector into a USB A female on a laptop or desktop PC.

Beep sounds

Three short beeps	Scanner is activated
One short beep	Bluetooth connection is established
Two short beeps	The scanner successfully reads a configuration barcode.
Two long beeps	Bluetooth connection disconnected
Three short beeps	a) The scanner reads a barcode although it is not connected. b) The scanner reads an unexpected barcode during configuration. (Scan [ABORT] to cancel and restart)
Two long beeps	Out of range / Bad connection
One long beep	Device switches off

Reset scanner



Connect with Bluetooth


To connect the device to Bluetooth, start the scanner, press trigger for 8 seconds and scan the barcode below and turn on the Bluetooth on your smartphone, notebook or tablet.



Now connect to "Scanner HID". If the connection was successful, you will hear a short tone.

If your system does not automatically connect to Bluetooth, you need to add the Bluetooth device first.

Or alternatively, for other profiles, select the desired barcode for the Bluetooth communication protocol.



Bluetooth HID Mode



Bluetooth SPP Mode



Bluetooth BLE Mode

Change name of Scanner

You have the possibility to change the name of the scanner via Bluetooth. You need to generate a name in advance using a barcode generator with the help of the barcode.

Scan the barcode below



Then scan the barcode you generated to change the name of the scanner. If you select the code from the example below, the name of the scanner changes to "Scanner 123".



With the following barcode you can fix the name of the scanner



To change the name permanently, you need to turn off the Bluetooth completely, remove the device from the list, reconnect and add the device again.

Hide keyboard (iOS)

With the code below you can enter the menu to activate or hide the keyboard of your iOS device.



Attention: if the scanner enters the matching state and does not successfully pair with Bluetooth within 1 minute, a double tone will be displayed to indicate a mismatch and return to scan mode

Menü to pull up and hide keyboard

This code below allows you to move up and down the keyboard by pressing the button twice.



Pull twice to pull up keyboard

This code below switches the function off again.



pull twice to hide keyboard

Sound and vibration setting



Switch off sound



Switch on sound



Turn on vibration

Connect via 2,4 GHz

Alternatively to Bluetooth, you can connect the scanner to your system via the 2.4 GHz frequency band.

Normally the scanner connects to the dongle automatically after it is connected to the system.

If not, please follow the instructions below.

For this, scan the dongle menu of the scanner



Connect to the dongle with the barcode below



Then plug the dongle into the USB socket provided for this purpose. If the connection was successful you will hear a beep. The blue light shines continuously
Attention: if the scanner enters the matching state and does not successfully pair up within 1 minute, a double beep is displayed indicating a mismatch and returns to scan mode

Set standby time



Standby after 1 minute



Standby after 5 minutes



Standby after 10 minutes



Standby after 30 minutes



Never switch to standby mode



Directly switch to standby mode

Change language



German



English



French



Spanish



Italian



Japanese



German (Swiss)

Settings End characters



Add CR



Add LF



Add CR + LF



Cancel CR + LF



Add TAB

Transmission speed

Select the appropriate transmission speed according to the PC reception speed.



fast



medium



slow



very slow

If not set otherwise, the scanned barcodes are displayed directly on the output device.

Data transfer via USB cable

Among the possibilities to output your data via Bluetooth or 2.4Ghz directly to the media, you have the possibility to connect the scanner to the system with a USB cable.

Usually, the scanner transfers the data directly to the output media when the cable is connected.

Data transfer from the save mode

If you are outside the transmission range to your Bluetooth device, you can save the codes directly in the scanner's memory. If the internal memory is full, you will hear three short beeps.

Use the code below for the internal storage mode.



You can now upload the stored data by scanning the barcode below



Please make sure that you are in the reception area of your USB device and that an ideal connection has been established. Otherwise, please use the enclosed USB cable for data transfer.

To delete the internal memory afterwards you can use the following code



Return to normal mode



Sicherheitshinweise

- Produkt vor Feuchtigkeit schützen
- Produkt vor direkter Sonneneinstrahlung schützen
- Schauen Sie nicht direkt in die Laser Diode des Scanners

Akku laden

Sie können den Akku des Scanners mit Hilfe des beiliegenden USB Kabels laden. Hierfür stecken Sie den Type B Stecker in den Scanner und den USB A Stecker in eine USB A Buchse am Notebook oder Desktop PC.

Piep Töne

Drei kurze Pieptöne	Scanner wird aktiviert
Ein kurzer Piepton	Bluetooth Verbindung hergestellt
Zwei kurze Pieptöne	Der Scanner liest erfolgreich einen Konfigurations-Barcode.
Zwei lange Pieptöne	Bluetooth Verbindung getrennt
Drei kurze Pieptöne	a) Der Scanner liest einen Barcode, obwohl er nicht verbunden ist. b) Der Scanner liest während der Konfigurierung einen unerwarteten Barcode. (Scannen Sie [ABORT] um abzubrechen und starten Sie neu)
zwei lange Pieptöne	Außerhalb der Reichweite / Schlechte Verbindung
Ein langer Piepton	Gerät schaltet sich aus

Reset scanner



Verbinden mit Bluetooth


Um das Gerät mit Bluetooth zu verbinden, scannen Sie unten stehenden Barcode und schalten Sie das Bluetooth an Ihrem Smartphone, Notebook oder Tablet ein.



Verbinden Sie sich nun mit „Barcode Scanner HID“. Wenn der Verbindungsaufbau erfolgreich war, hören Sie einen kurzen Ton.

Sollte sich Ihr System nicht automatisch mit Bluetooth verbinden, müssen Sie das Bluetoothgerät erst hinzufügen.

Oder wählen Sie alternativ für andere Profile den gewünschten Strichcode für das Bluetooth-Kommunikationsprotokoll



Bluetooth HID Mode



Bluetooth SPP Mode



Bluetooth BLE Mode

Namensänderung

Sie haben die Möglichkeit, den Namen des Scanners via Bluetooth zu ändern. Sie müssten sich im Vorfeld über einen Barcodegenerator einen Namen mit Hilfe des Barcodes generieren.

Scannen Sie den unten stehenden Barcode



Anschließend scannen Sie den von Ihnen generierten Barcode um den Namen des Scanners zu ändern. Wählen Sie den Code aus unten stehendem Beispiel, ändert sich der Name des Scanners zu „Scanner 123“.



Mit folgendem Barcode können Sie den Namen des Scanners fixieren



Um den Namen endgültig zu ändern, müssen Sie das Bluetooth komplett ausschalten, das Gerät aus der Liste entfernen, die Verbindung erneut herstellen und das erneut Gerät hinzufügen.

Tastatur verbergen (iOS)

Mit unten stehendem Code kommen Sie in das Menü um die Tastatur Ihres IOS Gerätes zu aktivieren oder zu verbergen.



Achtung: wenn der Scanner in den Abgleichzustand eintritt und er sich nicht innerhalb von 1 Minute erfolgreich mit Bluetooth koppelt, wird ein zweimaliger Ton angezeigt, der auf eine fehlerhafte Übereinstimmung hinweist und zum Scanmodus zurückkehrt

Menü für Hochziehen und verstecken der Tastatur

Dieser untenstehende Code ermöglicht es, dass Sie mit zweimaligem Auslösen der Drucktaste die Tastatur hoch bzw runterfahren können.



Zweimal auslösen um die Tastatur hochzuziehen

Dieser untenstehende Code schaltet die Funktion wieder aus.



Zweimal auslösen um die Tastatur zu verstecken

Sound und Vibrations Einstellungen



Töne ausschalten



Töne anschalten



Vibration einschalten

Verbinden via 2,4 GHz

Alternativ zu Bluetooth können Sie den Scanner über das 2,4 GHz Frequenzband mit Ihrem System verbinden.

Normalerweise verbindet sich der Scanner automatisch mit dem dongle, nachdem dieser am System angeschlossen wurde. Falls nicht, folgen Sie bitte unten stehender Anleitung.

Scannen Sie hierzu das Dongle Menü des Scanner



Verbinden Sie sich mit unten stehendem Barcode mit dem Dongle



Und stecken anschließend den Dongle in die dafür vorgesehene USB Buchse. Wenn die Verbindung erfolgreich war, hören Sie einen Piepton. Das blaue Licht leuchtet kontinuierlich. Achtung: wenn der Scanner in den Abgleichs Zustand eintritt und er sich nicht innerhalb von 1 Minute erfolgreich koppelt, wird ein zweimaliger Ton angezeigt, der auf eine fehlerhafte Übereinstimmung hinweist und zum Scanmodus zurückkehrt

Stand By Zeit einstellen



Standby nach einer Minute



Standby nach 5 Minuten



Standby nach 10 Minuten



Standby nach 30 Minuten



Niemals in den Standby Modus wechseln



Direkt in den Standby Modus wechseln

Tastatur Sprache ändern



Deutsch



Englisch



Französisch



Spanisch



Italienisch



Japanisch



Schweizerdeutsch

Einstellungen Endzeichen



Add CR



Add LF



Add CR + LF



Cancel CR + LF



Add TAB

Übertragungsgeschwindigkeit

Wählen Sie die entsprechende Übertragungsgeschwindigkeit entsprechend der PC-Empfangsgeschwindigkeit.



schnell



medium



langsam



sehr langsam

Wenn nicht anders eingestellt, werden die gescannten Barcodes direkt auf dem Ausgabegerät angezeigt.

Datenübertragung via USB Kabel

Zu den Möglichkeiten, Ihre Daten per Bluetooth oder 2,4Ghz zu direkt auf dem Medium auszugeben, haben Sie die Chance, den Scanner mit einem USB Kabel an dem System anzuschließen. Für gewöhnlich, überträgt der Scanner die Daten direkt auf das Ausgabemedium wenn das Kabel angeschlossen ist.

Datenübertragung aus dem Speichermodus

Falls Sie sich außerhalb der Übertragungsbereichweite zu Ihrem Bluetooth Gerät befinden, können Sie die Codes direkt im Speicher des Scanners speichern. Sollte der interne Speicher voll sein, hören Sie drei kurze Töne.

Über untenstehenden Code gelangen Sie in den internen Speichermodus.



Nach dem Scannen des obenstehenden Codes werden die Barcodes auf dem Gerät gespeichert.

Sie können die gespeicherten Daten hochladen indem Sie den untenstehenden Barcode scannen



Bitte stellen Sie sicher, dass Sie sich im Empfangsbereich Ihres USB Gerätes befinden und eine ideale Verbindung hergestellt wurde. Andernfalls nutzen Sie bitte das beiliegende USB Kabel zur Datenübertragung.

Um den internen Speicher im Anschluss wieder zu löschen, können Sie folgenden Code verwenden




Wieder in den normalen Modus zurückkehren



APPENDIX - ANHANG

Add Prefix




Add Suffix



!	
"	
#	
\$	
%	
&	
'	
(
)	
*	
+	
,	
-	
.	
/	
0	
1	
2	
3	
4	
5	

6	
7	
8	
9	
:	
;	
<	
=	
>	
?	
@	
A	
B	
C	
D	
E	
F	
G	
H	
I	
J	
K	
L	
M	
N	

O	
P	
Q	
R	
S	
T	
U	
V	
W	
X	
Y	
Z	
[
\	
]	
^	
_	
a	
b	
c	
d	
e	
f	
g	
h	

i	
j	
k	
l	
m	
n	
o	
p	
q	
r	
s	
t	
u	
v	
w	
x	
y	
z	
{	
	
}	
~	

Wenn Sie keinen Anhang mehr benötigen, setzen Sie den Scanner bitte auf Werkseinstellung zurück. Sämtliche Einstellungen (Töne, Geschwindigkeit ...) werden ebenfalls zurückgesetzt und müssen erneut eingestellt werden. Sollten Sie lediglich den Anhang ändern wollen scannen Sie hierzu den neuen Anhang ein.

If you no longer need an attachment, please reset the scanner to factory settings. All settings (tones, speed, etc.) will also be reset and must be set again. If you only want to change the attachment, scan the new attachment.

Hiding Pre and Post-characters

Hide pre-character



Hide post-character



Choose how many characters you want to hide.
Wählen Sie die Anzahl der Zeichen die Sie ausblenden wollen aus.

