

# Navilock Charger Plate for MAXI Charger C1037

## Description

This charging plate by Navilock enables you to charge different rechargeable batteries and can be used together with the Navilock Maxi Charger (item 61700).



**Item no. 65722**

EAN: 4043619657223

Country of origin: China

Package: Blister

## Technical details

- Suitable for
  - Casio: NP30
  - FUJI: NP60, NP120, BT3, S301, 1037, 1137, DL-S5, DL-S6, DV-4, OD525
  - Kodak: K5000, K5001
  - Nikon: ENEL5, EL5
  - Olympus: Li20B, VBA10, DL12, DB40
  - Ricoh: DB40, DB43
  - Samsung: 1037
  - Toshiba: BT3
- Model: C1037
- Voltage: 4.2 V / 600 mA

## System requirements

- Navilock 61700 Maxi Charger

## Package content

- Charging plate

---

## Images

